

Midland XTR error codes

- E1 MPU ROM/RAM error
- E2 No model/no channel data programmed
- E3 Synthesizer (VCO) out of lock
- E4 (check)sum error of channel data
- E5
- E6
- E7 Backup power down
- E8 Programmer interface error
- E9 Clone interface error

Midland SynTech II error codes

- E-00 ROM error
- E-01 RAM error
- E-02 Model not defined
- E-03 No channel groups defined
- E-04 No channels defined
- E-05 Memory check error
- E-06 Undefined channel assigned to group
- E-10 Synthesizer unlocked at center frequency
- E-11 Synthesizer unlocked
- E-50 Programming interface error

Midland Titan error codes

- E1 MCU ROM/RAM error
- E2 No model number and/or channel data programmed
- E3 Synthesizer unlock
- E4 Channel data checksum error
- E6 EEPROM write counter is over 100000
- E7 EEPROM backup data lost
- E8 Program communication error
- E9 Cloning error