

TITAN (LOW / MEDIUM POWER MODELS)

Notes:

A: For internal speaker operation, pins #5 and #6 are connected as shown.

B: For external speaker operation, remove pins #5 and #6 along with the jumper wire. Using Molex Mini-Fit Jr. female pins, the external speaker is connected to pins #4 and #6.

C: For carrier squelch systems, or for using CTCSS operation where the "Monitor" button is to be used on the radio front panel, and mic hang-up is not used, pin #3 is connected as shown.

D: For CTCSS operation, using a mic hang-up, cut the jumper to pin #3.

